




# Sony Clie PEG-SL10 Battery Harness Replacement

This guide will show you how to replace a faulty battery case with a new one.

Written By: Emily





## TOOLS:

- [Phillips #0 Screwdriver](#) (1)



## PARTS:


- [Battery Harness](#) (1)

## Step 1 — Battery Harness




- Remove the six screws holding the outside case of the Sony Clie.

## Step 2




- Remove the six screws holding the outer case.

### Step 3



- Remove the two screws holding the battery harness in place.


### Step 4



- Gently pull the power cable from the socket.



## Step 5



- The battery harness is now removed. Install the new harness in reverse order.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 06:28:06 PM.